

Tuning Instructions for ARION/VISIONASIA

1. Press Menu on your remote control
2. In the “search channel” menu screen, press down “▼” to highlight to "Manual Search" and press “OK”
3. Press down “▼” to highlight "Frequency”
4. Highlight frequency and if this number "12545" is not displaying, press the numbers 12545 from your remote.
5. Press down “▼” to highlight to "Symbol rate" It should be 22500. If not, then type in 22500
6. Press down “▼” to highlight to "Polarisation" It should be Vertical
7. FEC should be 3/4 (If it is 2/3, press “▶” to change to 3/4)
8. Network Search should be YES
9. FTA Only should be NO
10. Press Red button(UHF) on remote control to SEARCH
11. Press “OK” when the message “DO you want to save?” appears
12. The receiver will scan for channels.
13. It will list the new channels scanned
14. Press “OK” to save this search
15. Exit out of all MENUS.
16. Change channels till you come to the Zee Punjabi