

Technosat

Decoder Tuning instructions

1. Press Menu button from the remote
2. Go to Installations and go to Manual Search & press OK
3. Enter pin no.. 0000
4. Check the satellite name should be Optus B3 or Optus D2 if not then press right or left arrow key and select the same.
5. Press down arrow key to go to TP
6. Change the TP by pressing the right arrow to TP 5 or any other TP where the Trans freq. is 12545 if not then come down to trans freq and manually type 12545
7. Symbol Rate should be 22500 if not then press the numbers with remote
8. Polarization should be Vertical if not then press right arrow key and change to Vertical
9. Skew should be Off
10. Network search should be ON if not then press right arrow key and change to ON
11. Press down arrow key till the button "Search TP" and then right arrow key to move cursor to "Save" and press "OK"
12. Cursor will go back to Satellite name Optus B3
13. Check the signal strength it should be more than 50% if not then signals are not there channels will not get scanned.
14. Press down arrow key to highlight "Search TP" at bottom of page and press "OK"
15. Press OK (for "ALL") in information box
16. Wait till the channels are tuned.
17. Press "EXIT" button to get out of the main menu
18. Press OK to get a list of channels and then scroll the channels and look for ZOOM